

Street Airdamn Installation

1. Attach the brackets to the Airdamn in the up most position with the short bolts and star washers.
2. Position the Airdamn and brackets on the quick jack down tubes. The Airdamn can be positioned right up to the body or back from the body this is your choice.
3. Mark where to drill the holes in the down tubes and drill thru both sides.
4. Attach the brackets to the down tubes with the long bolts and the washer and locknut on the inside of the down tube.

*note: You will have to remove the center arc of the conveyor belt if you have an oil cooler installed.

