

Adjustable Air Splitter Installation

1. Remove quick jack assemblies from front of car.
2. Mount one of the side brackets to the splitter make sure pivot bolt is tight but adjustment bolts are slightly loose.
3. Place some protection along the edge of the grill opening like a rag, tape or cardboard.
4. Place the splitter with one side bracket in the grill opening.
5. Loosely reinstall the quickjack mount on the side with the bracket attached to the splitter.
6. The bracket goes on the quickjack mount and is held there with the quickjack bolt.
7. Install the other splitter bracket to the splitter. You will have to angle it so you can install the pivot bolt.
8. Install the other quickjack loosely. make sure everything is lined up and tighten quickjack bolts.
9. Set angle on splitter and tighten bracket bolts

