

Dead Pedal Box Installation

1. Cut a piece of paper 7" x 4.25" for a cut out template.
2. Position template on the inside of the driver's foot box outside panel.
3. Once you have a position you think will suite you mark the panel around the template.
4. Cut out the area marked.
5. Place dead pedal box in cutout and rivet along edge approximately every 2 inches.
6. If purchased install dead pedal.

