

Exhaust Hanger Installation

1. Remove the upper side pipe to j-pipe/catalytic converter bolt.
2. Install the angled tab pointing toward the engine on the upper side pipe bolt.
3. Install the U bracket over the 3/4" tube above j-pipe/catalytic converter.
4. Attach the lower turnbuckle eye to the angled tab.
5. Attach the rubber bushing to the U bracket.
6. Once everything is tight adjust the turnbuckle to position the sidepipe.
7. Lock turnbuckle with jam nut.

