

Rear View Mirror Instalation Instructions

1. Install jam nuts in window channel.
2. Attach mirror bracket to window channel with short screws.
3. Attach rear view mirror to mount with long screws and lock nuts.
4. Mirror can be set centered or off to one side as long as both jam nuts are in the channel.

