

Side View Mirror Bracket Installation

1. Remove one of the windshield side post screws.
2. Install the threaded rod into the side post where you removed the screw.
3. Tighten from the center of the threaded rod with a pair of pliers. Take care not to strip the threads from the brass insert. Make sure not to mess up the ends of the threaded rod. The center of the rod can be marred.
4. Once the threaded rod is tight, tighten the locknut against the windshield post.
5. Slip the side view bracket over the threaded rod.
6. On the bullet mirror there are three holes. Enlarge the hole closest to the edge so it will slip over the threaded rod or you can drill a hole for the threaded rod $5/8$ " from the edge of the mirror with the existing holes facing down for a cleaner look.
7. Install the mirror on the threaded rod and use the keps nut to hold in place.

